
The never ending story of polychlorinated paraffins:
New proposals to overcome the persistent quantification
problem and new environmental surveys



Michael Oehme, Jana Hüttig, Margot Reth and Zdenek Zencak
University of Basel

Physical properties of CP



Chloroparaffines (CP) are complex technical mixtures containing thousands of different isomers, congeners and homologues.

- Chlorine content varies between 30 and 70%.
- Technical CP-products are divided into 3 groups: short-chained (sCP, C₁₀₋₁₃), mediu-chained (mCP, C₁₄₋₁₇) and long-chained CP (ICP, C_{>17}).
- Colourless to yellowish, low to highly viskose liquids or waxy solids.
- Thermally stable up to 200-300 °C.
- Can contain additives/stabilisors.

Lit. Muir D. *et al.* in: The Handbook of Environmental Chemistry (Springer) **2000**, 3.

Physical properties of CP, continued



- > Water solubility between 20-1000 $\mu\text{g/l}$ (10-100 times higher than for PCB).
- > Vapour pressure comparable to PCB, toxaphene etc. ($1.5 \cdot 10^{-3}$ to $4 \cdot 10^{-6}$ Pa for C_{10} to C_{17} chain)
- > Henry constants comparable to PCB and other POPs (0.8 - 15 Pa m^3 mol^{-1}): Transfer water \rightarrow air and long range transport possible.
- > Highly lipophilic ($\log K_{\text{OW}}$ 5-7).

3

Toxicology



- > Low acute toxicity for mammals.
- > Short-chained CP toxic for aquatic organisms (fish).
- > Formation of liver, thyroid and kidney carcinomas at mice.
- > Teratogenic effects

Furthermore:

- > Persistent and high bioaccumulation (BCF ca. 5000 for sCP (rainbow trout))

4

Applications of CP



- High pressure additives in cutting oils.
- Plasticisers (z.B. PVC) and flame retardands.
- Additives in paints, surface coatings, sealants, glues.



Estimated CP-production worldwide ca. 380 000 t/year (2000).

Lit. OSPAR Commission, OSPAR Background Document on Short Chain Chlorinated Paraffins, 2001, No. 41, www.ospar.org.

5

Regulation of application



- Production of sCP banned in Germany since 1. Juni 2003.
- On action list of OSPAR (Convention of the protection of the marine Environment of the North-East Atlantic).
- On priority list of dangerous compounds of the European Water Directive.
- On HELCOM-list of immediate action.

Lit. OSPAR Commission, OSPAR Background Document on Short Chain Chlorinated Paraffins, 2001, No. 41, www.ospar.org.


6

**Standard procedure:
Mass spectrometry with electron capture negative ion detection:
ECNI-MS**

- CP only separatable into a few humps by high resolution gas chromatography (thousands of compounds)
- Detection of the [M-Cl]⁻-fragment of each congener- and formula group, respectively.

Combined with: - **high resolution MS (HRMS)**
- **low resolution MS (LRMS)**


- Simultaneous formation of [M-Cl]⁻, M⁻ and [M+Cl]⁻ results in disturbances between congeners of different degree of chlorination.
- Other polychlorinated compounds can interfere.
- Response factors depend strongly on degree of chlorination, gives systematic errors. No suitable reference standards.



Quantification of CP so far



- Quantification of 32 congener groups for sCP (C₉-C₁₃) and 28 for mCP (C₁₄-C₁₇), require 5-10 injections per extract!
- Mass overlaps between sCP and mCP at LRMS.



9

All C₉-C₁₁ (sCP) and C₁₄-C₁₆ (mCP) congener groups



PCA congener	Short chain PCAs		PCA congener	Medium chain PCAs	
	Most abundant isotope (100%)	Second abundant isotope		Most abundant isotope (100%)	Second abundant isotope
C ₉ H ₁₄ Cl ₆	298.9 (X+2)	300.9 (X+4, 64%)	C ₁₄ H ₂₀ Cl ₄	299.1 (X)	301.1 (X+2, 96%)
C ₉ H ₁₃ Cl ₇	332.9 (X+2)	334.9 (X+4, 80%)	C ₁₄ H ₂₀ Cl ₅	335.1 (X+2)	333.1 (X, 78%)
C ₉ H ₁₂ Cl ₈	366.9 (X+2)	368.9 (X+4, 96%)	C ₁₄ H ₂₀ Cl ₆	369.0 (X+2)	371.0 (X+4, 64%)
C ₉ H ₁₁ Cl ₉	402.8 (X+4)	400.8 (X+2, 89%)	C ₁₄ H ₂₀ Cl ₇	403.0 (X+2)	405.0 (X+4, 80%)
			C ₁₄ H ₂₀ Cl ₈	436.9 (X+2)	438.9 (X+4, 96%)
			C ₁₄ H ₂₁ Cl ₉	472.9 (X+4)	470.9 (X+2, 89%)
			C ₁₄ H ₂₀ Cl ₁₀	506.9 (X+4)	504.9 (X+2, 78%)
C ₁₀ H ₁₅ Cl ₄	243.1 (X)	245.1 (X+2, 96%)			
C ₁₀ H ₁₇ Cl ₅	279.0 (X+2)	277.0 (X, 78%)			
C ₁₀ H ₁₆ Cl ₆	312.9 (X+2)	314.9 (X+4, 64%)	C ₁₅ H ₂₃ Cl ₄	313.1 (X)	315.1 (X+2, 96%)
C ₁₀ H ₁₅ Cl ₇	346.9 (X+2)	348.9 (X+4, 80%)	C ₁₅ H ₂₇ Cl ₅	349.1 (X+2)	347.1 (X, 78%)
C ₁₀ H ₁₄ Cl ₈	380.9 (X+2)	382.9 (X+4, 96%)	C ₁₅ H ₂₆ Cl ₆	383.0 (X+2)	385.0 (X+4, 64%)
C ₁₀ H ₁₃ Cl ₉	416.8 (X+4)	414.8 (X+2, 89%)	C ₁₅ H ₂₆ Cl ₇	417.0 (X+2)	419.0 (X+4, 80%)
C ₁₀ H ₁₂ Cl ₁₀	450.8 (X+4)	448.8 (X+2, 78%)	C ₁₅ H ₂₆ Cl ₈	451.0 (X+2)	453.0 (X+4, 96%)
			C ₁₅ H ₂₇ Cl ₉	486.9 (X+4)	484.9 (X+2, 89%)
			C ₁₅ H ₂₆ Cl ₁₀	520.9 (X+4)	518.9 (X+2, 78%)
C ₁₁ H ₂₀ Cl ₄	257.1 (X)	259.1 (X+2, 96%)			
C ₁₁ H ₁₉ Cl ₅	293.0 (X+2)	291.0 (X, 78%)			
C ₁₁ H ₁₈ Cl ₆	327.0 (X+2)	329.0 (X+4, 64%)	C ₁₆ H ₃₀ Cl ₄	327.1 (X)	329.1 (X+2, 96%)
C ₁₁ H ₁₇ Cl ₇	360.9 (X+2)	362.9 (X+4, 80%)	C ₁₆ H ₃₀ Cl ₅	363.1 (X+2)	361.1 (X, 78%)
C ₁₁ H ₁₆ Cl ₈	394.9 (X+2)	396.9 (X+4, 96%)	C ₁₆ H ₃₀ Cl ₆	397.0 (X+2)	399.0 (X+4, 64%)
C ₁₁ H ₁₅ Cl ₉	430.9 (X+4)	428.9 (X+2, 89%)	C ₁₆ H ₃₂ Cl ₇	431.0 (X+2)	433.0 (X+4, 80%)
C ₁₁ H ₁₄ Cl ₁₀	464.8 (X+4)	462.8 (X+2, 78%)	C ₁₆ H ₃₂ Cl ₈	465.0 (X+2)	467.0 (X+4, 96%)
			C ₁₆ H ₃₃ Cl ₉	500.9 (X+4)	498.9 (X+2, 89%)
			C ₁₆ H ₃₂ Cl ₁₀	534.9 (X+4)	532.9 (X+2, 78%)

10

Our quantification improvement: Check of isotope signals




PCA congener	Isotope ratios			Possible origin of the signal in the s+mPCA mixture
	sPC	mPC	sPCA+mPC	
C ₁₄ H ₂₅ Cl ₄	-	-	-	
C ₁₄ H ₂₅ Cl ₅	-	0.75	0.78	mPCA
C ₁₄ H ₂₃ Cl ₄	0.54	1.74	1.56	mPCA
C ₁₄ H ₂₃ Cl ₅	1.19	1.30	1.29	mPCA
C ₁₄ H ₂₂ Cl ₄	0.63	1.07	1.06	mPCA
C ₁₄ H ₂₂ Cl ₅	-	1.09	1.13	mPCA
C ₁₅ H ₂₈ Cl ₄	1.56	-	1.52	sPCA
C ₁₅ H ₂₇ Cl ₅	0.74	0.91	0.75	sPCA
C ₁₅ H ₂₆ Cl ₄	0.60	1.87	1.32	a)
C ₁₅ H ₂₅ Cl ₅	-	1.33	1.27	mPCA
C ₁₅ H ₂₄ Cl ₄	-	1.07	1.09	mPCA
C ₁₅ H ₂₃ Cl ₅	-	1.11	1.23	mPCA

a) Identification not possible

➤ 1. Exact control of isotope signal to detect and eliminate mass interferences

11

Our quantification improvement: Retention time ranges



➤ 2. Exact determination of retention time ranges of the different congener groups.

See: M. Reth, M. Oehme, Anal. Bioanal. Chem. **378**, 1741 (2004)

12

Our quantification improvement: Response factors



Response factors are influenced by:


- Degree of chlorination of CP-mixture (most important).
- Distribution of chain length (maximum 2-3 % influence).
- Mean molecular weight (maximum 2-3 % influence).

Systematic quantification error of CP-mixtures with 51%, 55% and 63% chlorine content.

Sample	SCCP standard		
	51% Cl	55% Cl	63% Cl
51% Cl	1500 ng	616 ng (59 %)	159 ng (89%)
55% Cl	3655 ng (144%)	1500 ng	386 ng (74%)
63% Cl	14185 ng (846%)	5822 ng (288%)	1500 ng

13

However: Response factor correlates with degree of chlorination and can be corrected



Dependence between total response factor and degree of chlorination for seven sCP-mixtures (51-70 % chlorine content, 5 repetitions).


Remaining maximum errors after correction: typically ca. 5 %

14

Development of an alternative screening method for CP




- All CP-compounds have the fragments m/z 102 and m/z 91 in their mass spectra by loss of chlorine/ aromatisation.
- Further selectivity by MS/MS (m/z 105 \rightarrow 65, 91 \rightarrow 53)
- Response factors are nearly structure independent.
- sCP and mCP detectable simultaneously.
- Accuracy <20 %.
- Inexpensive instrumentation (MS-Ion trap for €60'000.-) or triple-quadrupole.



Technical sCP-mixture, 55.5% Cl

15

Example: CP in North Sea dab



16

A further alternative method:
Negative ion detection with $\text{CH}_2\text{Cl}_2 + \text{CH}_4$ as reagent gas




Addition of CH_2Cl_2 to CH_4 results in:

- Only $[\text{M}+\text{Cl}]^-$ adducts, therefore no CP interferences
- Response factors very little structure dependent.
- Also low chlorinated Cl_3 -congeners detectable.
- Ionisation of polychlorinated interferences suppressed by at least a factor of 20.
- Only method allowing to analyse sediments with a high matrix load.

17

CACI-MS and ECNI-MS chromatograms of a sediment sample with high matrix load



CACI: "Chlorine attachment chemical ionisation";
ECNI: "Electron capture negative ionisation"

18

Method comparability?



	Spiked amount (ng)	ECNI-HRMS (ng)	ECNI-LRMS (ng)	CH ₄ /CH ₂ Cl ₂ -NICI-LRMS (ng)	EI-MS/MS (ng)
sCP	1500	1731 error: 15%	1694 error: 13%	1346 error: -10%	*
mCP	1500	1358 error: -9.4%	1510 error: 0.7%	1454 error: -3%	*
Total amount	3000	3089 error: 3.0%	3204 error: 6.8%	2800 error: -6.7%	2848 error: -5%

* Separate determination not possible



Methods are comparable!

19

Which method to apply?



- **EI-MS/MS:** „Screening“ to detect the presence of CP and determination of total CP concentration.
- **CH₄/CH₂Cl₂-NICI (CACI):** Quantification and determination of congener pattern including Cl_{3/4}-congeners, or
- **ECNI-LRMS:** Quantification after response factor correction and determination of congener pattern (>Cl₄).

20

Conclusions methodology



- Alternative methods to ECNI-MS now available.
- Systematic errors of ECNCI by variable response factors minimised.
- Applied methods give comparable results.

21

CP-burden of North and Baltic Sea



- Information about CP contamination very scarce worldwide. Comparability of results hardly possible due to quantification problems.
- First study of CP concentration in fish and sediments from North and Baltic Sea. Also first **systematic** study worldwide.

22

Sample clean-up for CP in sediments



Extraction

Soxhlet-extraction of 2-50 g dair-dried sediment with 200 ml $\text{CH}_2\text{Cl}_2/n$ -hexane 1+1 (v/v) overnight.

Sulphur removal

during Soxhlet-extraction with aktivated copper powder

Clean-up and removal of interfering chlorinated compounds

1. Silicagel (44 % sulphuric acid conc.)
70 ml *n*-hexane and CH_2Cl_2 (1+1, v/v)
2. Florisil® (deactivated with 1.5 % water (w/w))
Fraction 1 (60 ml *n*-hexane and 5 ml CH_2Cl_2)
Fraction 2 (55 ml CH_2Cl_2 , CP fraction)


Screening

Determination of total sCP- and mCP-concentration by HRGC-EI-MS/MS
CID (*m/z*): 91 → 53, 102 → 65, 102 → 67

Determination of sCP- and mCP-concentrations
and congener profiles with HRGC-NICI-LRMS

23

Sampling sites and s+mCP concentrations in sediments (ng/g TM)




Sampline Aug/Sept 2001/2002 and May 2003

24

Chain length profiles

- ⇒ More mCP (>C₁₃) than sCP
- ⇒ C₁₄ dominates
- ⇒ sCP profiles North and Baltic sea similar, but different for suspended particulate matter from rivers
- ⇒ mCP profiles all very similar
- ⇒ s+mCP Concentrations in Nord and Baltic Sea comparable relative to TOC, but absolutely higher in Baltic Sea.

Origin of sCP?




- ⇒ Congener pattern in sediments rather similar to some technical sCP.
- ⇒ Same valid for mCP.

Group 1: SCCP 51.5% CI, Hordalub 17, 710 (2002 and 2004), 715 (2001), 718 (2001 and 2004), 721 (2002, 2004), ODER, RUDEN, ECKFBU, KS 8 (2003, 2004), KS 11 (2002, 2003 and 2004)

CP content of fish livers from North and Baltic Sea



AAC




- ⇒ Typically 5 livers pooled
- ⇒ Levels comparable to PCBs

27

CP concentrations in fish livers from the North Atlantic




AAC



- ⇒ Concentrations comparable to Baltic Sea

28


CP chain length distribution in cod livers: Comparison „Arctic“ versus Baltic Sea



- ⇒ Fraction of sCP higher in Arctic samples:
- ⇒ Fraktionation by atmospheric long range transport?
- ⇒ C₁₀/C₁₂-ratio:
Arctic 0.76 ± 0.36 Baltic Sea: 0.52 ± 0.36 (n=6).

29

CP congener patterns in fish liver: Species differences




- ⇒ Considerable differences between species
- ⇒ Also differences between individuals from the same species and same sampling site.
Reasons?

30

A view into the future of CP analysis?



AAC



- ⇒ Comprehensive two-dimensional, HRGC (GC x GC) allows the separation of CPs into chain length groups (here C₁₀-C₁₅) and according to degree of chlorination.
- ⇒ Examples show clearly that also other compounds are present in the CP fraction (impurities technical mixtures)

Harbour sediments

31

Conclusions: Fish livers



AAC

- s- and mCP concentrations in fish liver from North and Baltic Sea show no **species specific differences**.
- **s+mCP concentration ranges of North Sea** (54-3880 ng/g lipid, mean 985 ng/g lipid) and **Baltic Sea comparable** (90-3170 ng/g lipid, mean 615 ng/g lipid).
- Highest **s+mCP contents are >1 ppm**, comparable to **PCB burden**.
- **s+mCP concentrations in cod liver from background areas** (Lofot Islands/Iceland) are **lower** (46-265 ng/g lipid, mean 149 ng/g lipid) than in cod from North/Baltic Sea (range 62-3170 ng/g lipid, mean 622 ng/g lipid).
- Cp congener patterns can be different in individuals from the same species.
- Arctic char (200-2500 ng/g lipid, mean 1005 ng/g lipid) from the **Bear Island** has comparable CP content **as cod from North/Baltic Sea**.

32

Conclusions: Sediments



AAC

- **CP present in all sediments by EI-MS/MS (“screening”)** (5-377 ng/g dry weight (dw)).
- **Different analytical methods** give same results within **10-15 %**.
- **CP concentrations in sediments from the Baltic Sea** (45-377 ng/g dw) generally higher than in **North Sea** (5-355 ng/g dw, 10 of 16 samples <50 ng/g dw). However comparable **on TOC basis** (North Sea 2.3-33.1 ng/g TOC, Baltic sea 2.1-9.4 ng/g TOC) .
- **TOC content good indicator for CP content.**
- **Highest CP concentrations** at sites **KS8 and KS11** (Waste and sewage sludge dump sites).
- **mCP concentrations** (C₁₄₋₁₆, 42-303 ng/g dw) **always higher than sCP levels** (C₁₀₋₁₃, 18-128 ng/g dw). Ratio mCP/sCP 1,7-3,2.

33

Acknowledgement



AAC

Many thanks to my former PhD students Zdenek Zencak, Jana Hüttig and Margot Reth,
as well as for the financial support to the German Federal Environmental Agency and the Swiss Science Foundation.

34